

SSID: CableComm_

The 4-character SSID on side of the modem.

SSID: CableComm_ -5G

The 4-character SSID on side of the modem.

5G—FASTEST OPTION

PASSWORD:

16-character PSK on side of the modem.

Example—
Label on the
side of Modem




Network Name (SSID):
2.4GHz: ARRIS-****
5GHz: ARRIS-****_5G
PSK: *****
Security Mode: WPA2-PSK(AES)
WPS PIN: *****



PLEASE NOTE: Wireless is provided for your convenience. Wireless is not a perfect technology and can be susceptible to interference. For the best performance, connect to all Broadband services through the network Ethernet cable provided.

UNDERSTANDING YOUR MODEM LIGHTS



- 1 **POWER LIGHT:** This indicates that modem is switched on and power is on.
- 2 **US/DS:** This light should be solid (not flashing), indicating that the modem is connected to Cablecomm network.
- 3 **ONLINE LIGHT:** This light means the modem is online and connected to the internet.
- 4 **2.4GHz:** This light will flash when a device is connected to 2.4GHz WiFi.
- 5 **5GHz:** This light will flash when a device is connected to 5GHz WiFi.
- 6 **Tel 1:** This light will be on if you have a landline service on Line 1.
- 7 **Tel 2:** This light will be on if you have a landline service on Line 2.

Tips & Tricks

GETTING THE MOST OF YOUR CONNECTION

www.cablecomm.ie/tips-and-tricks/